



**TANGO**  
Device  
Server

# TANGO Device Server User's Guide

## HqpsRotMachine Class

Revision: releasetag - Author: goudard  
Implemented in Python

### Introduction:

This class is a high level class for the HQPS system. Each device is the summary of state and status for each HQPS rotating machine. One rotating machine means: One accumulator, one alternator, 3 circuit breakers (dlvx, d1 and d2), one transformer and one common

### Class Identification:

- **Contact** : at esrf.fr - goudard
- **Class Family** : Hqps (Specific Specific)
- **Platform** : All Platforms
- **Bus** : Not Applicable

### Class Inheritance:

- PyTango.Device\_4Impl
  - HqpsRotMachine

## Properties:

Device Properties		
Property name	Property type	Description
Devices	Tango::DEVVAR_STRINGARRAY	Low level devices name

Device Properties Default Values:

Property Name	Default Values
Devices	No default value

**There is no Class properties.**

## Commands:

More Details on commands....

Device Commands for Operator Level		
Command name	Argument In	Argument Out
Init	DEV_VOID	DEV_VOID
State	DEV_VOID	DEV_STATE
Status	DEV_VOID	CONST_DEV_STRING

### 1 - Init

- **Description:** This commands re-initialise a device keeping the same network connection. After an Init command executed on a device, it is not necessary for client to re-connect to the device. This command first calls the device *delete\_device()* method and then execute its *init\_device()* method. For C++ device server, all the memory allocated in the *nit\_device()* method must be freed in the *delete\_device()* method. The language device desctructor automatically calls the *delete\_device()* method.
- **Argin:**  
**DEV\_VOID** : none.

- **Argout:**  
**DEV\_VOID** : none.
- **Command allowed for:**

## 2 - State

- **Description:** This command gets the device state (stored in its *device\_state* data member) and returns it to the caller.
- **Argin:**  
**DEV\_VOID** : none.
- **Argout:**  
**DEV\_STATE** : State Code
- **Command allowed for:**

## 3 - Status

- **Description:** This command gets the device status (stored in its *device\_status* data member) and returns it to the caller.
- **Argin:**  
**DEV\_VOID** : none.
- **Argout:**  
**CONST\_DEV\_STRING** : Status description
- **Command allowed for:**

TANGO is an open source project hosted by :  
**SOURCEFORGE.NET**<sup>®</sup>

Core and Tools : CVS repository on tango-cs project  
Device Servers : CVS repository on tango-ds project