



TANGO
Device
Server

Paragon Stepper Motor User's Guide

Paragon Class

Revision: Paragon-Release_2_0 - Author: vedder
Implemented in C++ - CVS repository: ESRF

Introduction:

A class to control stepper motors with the DIN Rail Stepper Drive L25i/L50i.

Class Inheritance:

- Tango::Device_4Impl
 - Paragon

Class Description:

Properties:

Device Properties		
Property name	Property type	Description
Serialline	Tango::DEV_STRING	Serial line device to access the motor controller.
Channel	Tango::DEV_SHORT	Channel number for the motor on the controller. Number between 1 and 6.
Limit_switches	Tango::DEV_STRING	Limit switches can be 'enabled' or 'disabled'.
Acceleration	Tango::DEV_DOUBLE	Motor Acceleration
Steps_per_unit	Tango::DEV_DOUBLE	Motors steps per unit of the position value. Position might have a unit as: mm, um, rad, mrad....
Velocity	Tango::DEV_DOUBLE	Constant velocity of the motor
Current	Tango::DEV_LONG	Current to drive motor in
Micro_stepping	Tango::DEV_LONG	Multiplies the steps/tr of the motor by the micro_stepping value.
Backlash	Tango::DEV_DOUBLE	Backlash to be applied with every motor movement.
Encoder_present	Tango::DEV_SHORT	The motor position is read either in motor steps (=0) or in encoder steps (=1).
Encoder_input	Tango::DEV_SHORT	Refer to Paragon stepper drive user's guide. 9=step/dir, 1=cw/ccw, 2=quad ABZ, default=2
Encoder_resolution	Tango::DEV_LONG	Resolution of the encoder connected to the axe.
Home_switch_edge	Tango::DEV_STRING	The reference edge of the home switch to be used for the home positioning. The value can either be the rising edge (+) or falling edge (-).
Home_switch_type	Tango::DEV_SHORT	The home switch used can be normally in a open = 0 or a closed = 1 position.
Home_search_direction	Tango::DEV_STRING	Direction to search for the home switch + or -.
Home_mode	Tango::DEV_SHORT	The mode determines what happens when the specified edge of the home switch is encountered: See the stepper drive user guide for a detailed description
Home_position	Tango::DEV_DOUBLE	The position value to be applied to the motor in the home position.
Posmain	Tango::DEV_STRING	Position mainenance can be \"enabled\" or \"disabled\".
Posmain_deadband_range	Tango::DEV_LONG	The dead band range is measured in encoder counts as a +/- band. A dead band of 10 will be 20 units wide
Posmain_settle_time	Tango::DEV_LONG	Time in milliseconds the indexer will wait after a motion, before doing a feedback.
Calibrated	Tango::DEV_SHORT	When this property is different from 0, the motor is considered as calibrated and a certain number of attributes cannot be changed anymore.(e.g. step_per_unit) The goal is to avoid undesired change when the calibratiou process has been performed.

Position	Tango::DEV_DOUBLE	The last position value saved to the database by the server. Must be written to the controller on start-up.
Auto_numbering	Tango::DEV_STRING	Defines if the controller is configured to accept the auto numbering. This feature is only available with RS232 controlled devices. This property is set by default to \"ON\" in the code of the server. It should be set to \"OFF\" to disable it.
BrakeMask	Tango::DEV_STRING	This is a string representing the mask to be applied to the output bits in order to activate or de-activate the brake mechanism. All the bits set to 'x' will not be changed, only the bit set to '1'.

Device Properties Default Values:

Property Name	Default Values
Serialline	No default value
Channel	No default value
Limit_switches	enabled
Acceleration	10
Steps_per_unit	1
Velocity	1
Current	50
Micro_stepping	20
Backlash	0
Encoder_present	0
Encoder_input	2
Encoder_resolution	1
Home_switch_edge	+
Home_switch_type	0
Home_search_direction	-
Home_mode	2
Home_position	0
Posmain	disabled
Posmain_deadband_range	0
Posmain_settle_time	0
Calibrated	0
Position	No default value
Auto_numbering	No default value
BrakeMask	XXXXXXXX

There is no Class properties.

States:

States

Names	Descriptions
ON	The motor powered on and is ready to move.
MOVING	The motor is moving
FAULT	The motor indicates a fault.
ALARM	The motor indicates an alarm state for example has reached a limit switch.
OFF	The power on the moror drive is switched off.
DISABLE	The motor is in slave mode and disabled for normal use

Attributes:

Scalar Attributes

Attribute name	Data Type	R/W Type	Expert
Position: The actual motor position.	DEV_DOUBLE	READ_WRITE	No
Tweak_step: Step size to move the motor when executing the 'Tweak' command.	DEV_DOUBLE	READ_WRITE	No
Steps_per_unit	DEV_DOUBLE	READ_WRITE	Yes
Acceleration: The acceleration of the motor.	DEV_DOUBLE	READ_WRITE	Yes
Velocity: The constant velocity of the motor.	DEV_DOUBLE	READ_WRITE	Yes
Current: The current used to drive the motor.	DEV_LONG	READ_WRITE	Yes
Micro_stepping	DEV_LONG	READ_WRITE	Yes
Backlash: Backlash to be applied to each motor movement	DEV_DOUBLE	READ_WRITE	Yes
Steps	DEV_LONG	READ	No
Encoder_present: 0 = False 1= True	DEV_SHORT	READ_WRITE	Yes
Encoder_input	DEV_SHORT	READ_WRITE	Yes
Encoder_resolution	DEV_LONG	READ_WRITE	Yes
Home_switch_edge	DEV_STRING	READ_WRITE	Yes
Home_switch_type: Pulse switch: 0=normally open; 1=normally closed. Simple switch: 3=switch from open to close.	DEV_SHORT	READ_WRITE	Yes
Home_search_direction	DEV_STRING	READ_WRITE	Yes
Home_mode	DEV_SHORT	READ_WRITE	Yes
Home_position	DEV_DOUBLE	READ_WRITE	Yes
Position_error	DEV_LONG	READ	No
Posmain_deadband_range: The dead band range is measured in encoder counts as a +/- band. A dead band of 10 will be 20 units wide!	DEV_LONG	READ_WRITE	Yes
Posmain_settle_time: Time in milliseconds the indexer will wait after a motion, before doing a feedback	DEV_LONG	READ_WRITE	Yes
Limits_status: limits_status[0] = Home (0 or 1 (or X->communication pb)) limits_status[1] = Limit - (0 or 1 (or X->communication pb)) limits_status[2] = Limit +(0 or 1 (or X->communication pb))	DEV_STRING	READ	Yes

Commands:

More Details on commands....

Device Commands for Operator Level		
Command name	Argument In	Argument Out
Init	DEV_VOID	DEV_VOID
State	DEV_VOID	DEV_STATE
Status	DEV_VOID	CONST_DEV_STRING
Tweak	DEV_VOID	DEV_VOID
On	DEV_VOID	DEV_VOID
Off	DEV_VOID	DEV_VOID
GoHome	DEV_VOID	DEV_VOID
Abort	DEV_VOID	DEV_VOID
BrakeOn	DEV_VOID	DEV_VOID
BrakeOff	DEV_VOID	DEV_VOID

Device Commands for Expert Level Only		
Command name	Argument In	Argument Out
WriteAbsolutePosition	DEV_DOUBLE	DEV_VOID
PosmainOn	DEV_VOID	DEV_VOID
PosmainOff	DEV_VOID	DEV_VOID

1 - Init

- **Description:** This commands re-initialise a device keeping the same network connection. After an Init command executed on a device, it is not necessary for client to re-connect to the device. This command first calls the device *delete_device()* method and then execute its *init_device()* method. For C++ device server, all the memory allocated in the *nit_device()* method must be freed in the *delete_device()* method. The language device desctructor automatically calls the *delete_device()* method.
- **Argin:**
DEV_VOID : none.
- **Argout:**
DEV_VOID : none.
- **Command allowed for:**
 - Tango::ON
 - Tango::MOVING
 - Tango::FAULT

- Tango::ALARM
- Tango::OFF
- Tango::DISABLE

2 - State

- **Description:** This command gets the device state (stored in its *device_state* data member) and returns it to the caller.

- **Argin:**
DEV_VOID : none.

- **Argout:**
DEV_STATE : State Code

- **Command allowed for:**
 - Tango::ON
 - Tango::MOVING
 - Tango::FAULT
 - Tango::ALARM
 - Tango::OFF
 - Tango::DISABLE

3 - Status

- **Description:** This command gets the device status (stored in its *device_status* data member) and returns it to the caller.

- **Argin:**
DEV_VOID : none.

- **Argout:**
CONST_DEV_STRING : Status description

- **Command allowed for:**
 - Tango::ON
 - Tango::MOVING
 - Tango::FAULT
 - Tango::ALARM
 - Tango::OFF
 - Tango::DISABLE

4 - Tweak

- **Description:** Tweak the motor by the value of the tweak_step attribute value.
- **Argin:**
DEV_VOID :
- **Argout:**
DEV_VOID :
- **Command allowed for:**
 - Tango::ON
 - Tango::ALARM

5 - On

- **Description:** Enable power on motor
- **Argin:**
DEV_VOID :
- **Argout:**
DEV_VOID :
- **Command allowed for:**
 - Tango::ON
 - Tango::ALARM
 - Tango::OFF

6 - Off

- **Description:** Desable power on motor
- **Argin:**
DEV_VOID :
- **Argout:**
DEV_VOID :
- **Command allowed for:**
 - Tango::ON
 - Tango::ALARM
 - Tango::OFF

7 - WriteAbsolutePosition (for expert only)

- **Description:** Define an absolute position
- **Argin:**
DEV_DOUBLE :
- **Argout:**
DEV_VOID :
- **Command allowed for:**
 - Tango::ON
 - Tango::ALARM
 - Tango::OFF

8 - GoHome

- **Description:** Move the motor to the home position given by a home switch.
- **Argin:**
DEV_VOID :
- **Argout:**
DEV_VOID :
- **Command allowed for:**
 - Tango::ON
 - Tango::ALARM

9 - PosmainOn (for expert only)

- **Description:** Switch on position maintenance feedback.
- **Argin:**
DEV_VOID :
- **Argout:**
DEV_VOID :
- **Command allowed for:**
 - Tango::ON
 - Tango::ALARM
 - Tango::OFF

10 - PosmainOff (for expert only)

- **Description:** Switch off position maintenance feedback.
- **Argin:**
DEV_VOID :
- **Argout:**
DEV_VOID :
- **Command allowed for:**
 - Tango::ON
 - Tango::ALARM
 - Tango::OFF

11 - Abort

- **Description:** Abort a movement of the motor.
- **Argin:**
DEV_VOID :
- **Argout:**
DEV_VOID :
- **Command allowed for:**
 - Tango::ON
 - Tango::MOVING
 - Tango::FAULT
 - Tango::ALARM
 - Tango::OFF
 - Tango::DISABLE

12 - BrakeOn

- **Description:** Activate the brake mechanism.
- **Argin:**
DEV_VOID :
- **Argout:**
DEV_VOID :
- **Command allowed for:**
 - Tango::ON
 - Tango::MOVING

- Tango::FAULT
- Tango::ALARM
- Tango::OFF
- Tango::DISABLE

13 - BrakeOff

- **Description:** De-activate the brake mechanism.

- **Argin:**
DEV_VOID :

- **Argout:**
DEV_VOID :

- **Command allowed for:**

- Tango::ON
- Tango::MOVING
- Tango::FAULT
- Tango::ALARM
- Tango::OFF
- Tango::DISABLE

TANGO is an open source project hosted by :
SOURCEFORGE.NET[®]

Core and Tools : CVS repository on tango-cs project
Device Servers : CVS repository on tango-ds project