



TANGO
Device
Server

RF Cavity wrapper User's Guide

RFCavityWrapper Class

**Revision: FirstRelease - Author: vedder
Implemented in C++ - CVS repository: ESRF**

Introduction:

This TANGO class will wrap TACO High level server for the control of the rf cavities.

Class Identification:

- **Contact** : at esrf.fr - vedder
- **Class Family** : RadioFrequency (Specific Specific)
- **Platform** : All Platforms
- **Bus** : Not Applicable

Class Inheritance:

- Tango::Device_4Impl
 - RFCavityWrapper

Properties:

Device Properties		
Property name	Property type	Description
Cavity_taco_device	Tango::DEV_STRING	This is the TACO high level server that will be wrapped.
Hardware_access_delay	Tango::DEV_USHORT	Read on taco server are done in one pass. This property is the delay between two access to the taco device. This is done to avoid taco access on each attribute read.
Configuration_file_path	Tango::DEV_STRING	This is the default configuration file directory.

Device Properties Default Values:

Property Name	Default Values
Cavity_taco_device	No default value
Hardware_access_delay	3
Configuration_file_path	No default value

There is no Class properties.

Attributes:

Scalar Attributes			
Attribute name	Data Type	R/W Type	Expert
Cavity_mode	DEV_STRING	READ	No
Configuration_file	DEV_STRING	READ	No
Cavity_1_voltage	DEV_DOUBLE	READ	No
Cavity_2_voltage	DEV_DOUBLE	READ	No
Cavity_1_vacuum	DEV_DOUBLE	READ	No
Cavity_2_vacuum	DEV_DOUBLE	READ	No
Tuner_1_cav_l_pos	DEV_DOUBLE	READ	No
Tuner_1_cav_r_pos	DEV_DOUBLE	READ	No
Tuner_2_cav_l_pos	DEV_DOUBLE	READ	No
Tuner_2_cav_r_pos	DEV_DOUBLE	READ	No
Configuration_file_path	DEV_STRING	READ	No
ShortStatus	DEV_STRING	READ	No

Spectrum Attributes			
Attribute name	Data Type	X Data Length	Expert
SubDevicesStates	DEV_STATE	22	No
SequenceHistory	DEV_STRING	4096	No

Commands:

More Details on commands....

Device Commands for Operator Level		
Command name	Argument In	Argument Out
Init	DEV_VOID	DEV_VOID
State	DEV_VOID	DEV_STATE
Status	DEV_VOID	CONST_DEV_STRING
On	DEV_VOID	DEV_VOID
Off	DEV_VOID	DEV_VOID
Stop	DEV_VOID	DEV_VOID
Reset	DEV_VOID	DEV_VOID
ReadConfigurationFile	DEV_STRING	DEV_VOID
WriteConfigurationFile	DEV_STRING	DEV_VOID
GetConfigurationFilePath	DEV_VOID	DEV_STRING

1 - Init

- Description:** This commands re-initialise a device keeping the same network connection.
 After an Init command executed on a device, it is not necessary for client to re-connect to the device.
 This command first calls the device *delete_device()* method and then execute its *init_device()* method.
 For C++ device server, all the memory allocated in the *nit_device()* method must be freed in the *delete_device()* method.
 The language device desctructor automatically calls the *delete_device()* method.
- Argin:**
DEV_VOID : none.
- Argout:**
DEV_VOID : none.

- **Command allowed for:**

2 - State

- **Description:** This command gets the device state (stored in its *device_state* data member) and returns it to the caller.
- **Argin:**
DEV_VOID : none.
- **Argout:**
DEV_STATE : State Code
- **Command allowed for:**

3 - Status

- **Description:** This command gets the device status (stored in its *device_status* data member) and returns it to the caller.
- **Argin:**
DEV_VOID : none.
- **Argout:**
CONST_DEV_STRING : Status description
- **Command allowed for:**

4 - On

- **Description:**
- **Argin:**
DEV_VOID :
- **Argout:**
DEV_VOID :
- **Command allowed for:**

5 - Off

- **Description:**
- **Argin:**
DEV_VOID :
- **Argout:**
DEV_VOID :
- **Command allowed for:**

6 - Stop

- **Description:**
- **Argin:**
DEV_VOID :
- **Argout:**
DEV_VOID :
- **Command allowed for:**

7 - Reset

- **Description:**
- **Argin:**
DEV_VOID :
- **Argout:**
DEV_VOID :
- **Command allowed for:**

8 - ReadConfigurationFile

- **Description:** Load a configuration file (wraps DevRead taco command).
- **Argin:**
DEV_STRING :
- **Argout:**
DEV_VOID :

- **Command allowed for:**

9 - WriteConfigurationFile

- **Description:** Save a configuration file (wraps DevWrite taco command).
- **Argin:**
DEV_STRING :
- **Argout:**
DEV_VOID :
- **Command allowed for:**

10 - GetConfigurationFilePath

- **Description:** Configuration_file_path device property is returned by this command.
- **Argin:**
DEV_VOID :
- **Argout:**
DEV_STRING : Configuration_file_path is returned.
- **Command allowed for:**

TANGO is an open source project hosted by :
SOURCEFORGE.NET[®]

Core and Tools : CVS repository on tango-cs project
Device Servers : CVS repository on tango-ds project