



TANGO
Device
Server

Linac Gun Auxiliary User's Guide

LinacGunAux Class

Revision: LinacGunAux-Release_1_1 - Author: vedder
Implemented in C++ - CVS repository: ESRF

Introduction:

This class will manage the gun auxiliary of the Linac.

Class Inheritance:

- Tango::Device_4Impl
 - LinacGunAux

Class Description:

Properties:

Device Properties		
Property name	Property type	Description
Daresbury	Tango::DEV_STRING	Name of the daresbury device.
Heat_time	Tango::DEV_LONG	Heating time (in seconds).
HeatI_adc	Tango::DEV_STRING	ADC device to read the Heating Current.
HeatV_adc	Tango::DEV_STRING	ADC device to read the Heating Voltage.
HeatV_dac	Tango::DEV_STRING	DAC device to set the heating voltage.
Interlocks_list	Array of double	list of interlocks.
Offrelay	Tango::DEV_STRING	Name of the relay used to switch off the Gun Auxiliary.
Onrelay	Tango::DEV_STRING	Name of the relay used to switch on the gun auxiliary.
Pulsetime	Tango::DEV_LONG	Duration in milliseconds of the pulse to do on the pulsed relays.
Stateheatnum	Tango::DEV_DOUBLE	Daresbury relay number which indicates if the device is heating or not.
Stateonnum	Tango::DEV_DOUBLE	Daresbury relay number used to determine whether the gun auxiliary is on or not.

Device Properties Default Values:

Property Name	Default Values
Daresbury	No default value
Heat_time	No default value
HeatI_adc	No default value
HeatV_adc	No default value
HeatV_dac	No default value
Interlocks_list	No default value
Offrelay	No default value
Onrelay	No default value
Pulsetime	No default value
Stateheatnum	No default value
Stateonnum	No default value

There is no Class properties.

States:

States	
Names	Descriptions
FAULT	*
MOVING	*
OFF	*
ON	*
DISABLE	The device can't be switch ON.

Attributes:

Scalar Attributes			
Attribute name	Data Type	R/W Type	Expert
HeatI: Heating current	DEV_DOUBLE	READ	No
HeatV: Heating Voltage	DEV_DOUBLE	READ_WRITE	No
Temporization: remaining time before the ON state.	DEV_SHORT	READ	No

Commands:

More Details on commands....

Device Commands for Operator Level		
Command name	Argument In	Argument Out
Init	DEV_VOID	DEV_VOID
State	DEV_VOID	DEV_STATE
Status	DEV_VOID	CONST_DEV_STRING
On	DEV_VOID	DEV_VOID
Off	DEV_VOID	DEV_VOID
Reset	DEV_VOID	DEV_VOID

1 - Init

- **Description:** This commands re-initialise a device keeping the same network connection. After an Init command executed on a device, it is not necessary for client to re-connect to the device. This command first calls the device *delete_device()* method and then execute its *init_device()* method. For C++ device server, all the memory allocated in the *nit_device()* method must be freed in the *delete_device()* method.
The language device desctructor automatically calls the *delete_device()* method.
- **Argin:**
DEV_VOID : none.
- **Argout:**
DEV_VOID : none.
- **Command allowed for:**
 - Tango::FAULT
 - Tango::MOVING
 - Tango::OFF
 - Tango::ON
 - Tango::DISABLE

2 - State

- **Description:** This command gets the device state (stored in its *device_state* data member) and returns it to the caller.
- **Argin:**
DEV_VOID : none.
- **Argout:**
DEV_STATE : State Code

- **Command allowed for:**

- Tango::FAULT
- Tango::MOVING
- Tango::OFF
- Tango::ON
- Tango::DISABLE

3 - Status

- **Description:** This command gets the device status (stored in its *device_status* data member) and returns it to the caller.

- **Argin:**

DEV_VOID : none.

- **Argout:**

CONST_DEV_STRING : Status description

- **Command allowed for:**

- Tango::FAULT
- Tango::MOVING
- Tango::OFF
- Tango::ON
- Tango::DISABLE

4 - On

- **Description:**

- **Argin:**

DEV_VOID :

- **Argout:**

DEV_VOID :

- **Command allowed for:**

- Tango::FAULT
- Tango::MOVING
- Tango::OFF
- Tango::ON
- Tango::DISABLE

5 - Off

- **Description:**
- **Argin:**
DEV_VOID :
- **Argout:**
DEV_VOID :
- **Command allowed for:**
 - Tango::FAULT
 - Tango::MOVING
 - Tango::OFF
 - Tango::ON
 - Tango::DISABLE

6 - Reset

- **Description:**
- **Argin:**
DEV_VOID :
- **Argout:**
DEV_VOID :
- **Command allowed for:**
 - Tango::FAULT
 - Tango::MOVING
 - Tango::OFF
 - Tango::ON
 - Tango::DISABLE

TANGO is an open source project hosted by :
SOURCEFORGE.NET®

Core and Tools : CVS repository on tango-cs project
Device Servers : CVS repository on tango-ds project